

# TAP BRACKET™

## INSTRUCTION MANUAL



Distributed by  
Supertek Canada Inc.  
Mont-Royal, QC  
H4T 1X2

**Customer Service:**  
**1-800-304-8354**

- **No Screws Needed**
- **No Damage to Walls**

[www.clikit.ca](http://www.clikit.ca)

### To Install:

You will need a hammer or mallet to install your Tap Brackets. Place Tap Bracket on the top corner of wooden window trim, making sure the back of the bracket is flush with the wall. Tap down into place with hammer. Repeat on the other side of window. Not recommended for curtains over 30 lbs.

### To Remove:

Simply lift up Tap Bracket to remove from window trim. In some cases you may need to tap up with hammer. Tap Brackets can be removed and reinstalled on windows as needed.

Note: Does not work on vinyl window frames.