

# PocketMouse™



## INSTRUCTION MANUAL

- 2.4GHz wireless connection
- Faster web browsing
- Ergonomic pen shape

### To Install Battery:

- Locate the battery compartment cover on the top of the unit.
- Pull the battery compartment cover off.
- Insert 1 “AAA” battery (not included) and replace the battery compartment cover by pushing it gently until it clicks in place.
- Do not mix old and new batteries. Do not mix alkaline, standard or rechargeable batteries

### Easy to Use with Any Device:

- Plug the USB receiver in your computer's USB port.
- Turn the Pocket Mouse on using the On/Off switch.
- Pocket Mouse and the USB receiver have already been paired so Pocket Mouse is ready to use.
- To use, simply slide Pocket Mouse over any horizontal or vertical surface to scroll, draw, write, click, web browse, and swipe with ease—up to 30 ft. away.
- Can also be used as a stylus, simply flip over.

### Adjustable DPI:

- Choose either 800/1200/1600 DPI resolution.



FCC ID Mouse: 2AN77-PM-MC12T  
FCC ID USB: 2AN77-PM-MC12R

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Specifications:

- Supports WinXP/Win7/Win8/Win10/Linux/macOS
- Working voltage: DC 1.5V
- Working current: 7mA
- Standby current: <0.1 mA
- USB jack: USB 2.0
- Effective distance: 10m
- DPI: 800/1200/1600 (default is 1200 DPI)



### LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. Supertek Canada Inc. shall not be liable for any incidental or consequential damages or any implied warranty on this product.

Distributed by

**IT Supertek™**

Mont-Royal, QC H4T 1X2  
[www.supertek.ca/pocket-mouse](http://www.supertek.ca/pocket-mouse)

**Customer service :**  
**1-800-304-8354**

©2018 All Rights Reserved • Made In China