


Dermaline™ 3-in-1 Personal Hair Remover

DERMALINE™



Includes:

- 1 Dermaline™ Hair Remover
- 1 Facial Head **A**
- 1 Brows Head **B**
- 1 Body Hair Remover Head **C**
- 3 Comb Attachments 2mm, 4mm, & 6mm
- 1 Head Cleaning Brush
- 1 Carrying Case
- 1 AAA Battery

INSTRUCTIONS

The 3-in-1 Dermaline™ Hair Remover comes with the Brows Head attached. The Brows Head, Facial Head and Body Hair Remover Head are interchangeable. To remove/change heads, remove cap from unit body then gently twist head counterclockwise. (Fig. 1) Select desired head and gently twist clockwise to lock onto unit.

INSTALL BATTERY

Twist cap on unit bottom counterclockwise. (Fig.2) and insert included AAA battery into battery compartment with the - end facing up and the + facing down (bottom of unit). (Fig.3) Twist cap clockwise to close battery compartment.

TURN UNIT ON

Press button on bottom of unit. (Fig.4)

NOTE: Before first use, It is recommended that you test the unit on a small area. If sensitivity or allergic reactions occur, discontinue use. Use on clean, dry skin.

A: FACIAL HEAD – TO REMOVE FACIAL HAIR & PEACH FUZZ.

Gently press unit head flat against your skin and make small circular motions to remove hair. Do not hold unit on an angle. (Fig.5)






B: BROWS HEAD – TO REMOVE HAIR AND SHAPE EYEBROWS

Pull skin taught and move unit in small, circular motions to remove hair. (Fig.6)

C: BODY HAIR REMOVER – FOR THICKER HAIR AREAS SUCH AS ARMS & SIDEBURNS

Hold unit with blade against skin at a perpendicular angle and gently remove hair. (Fig.7)

NOTE: If skin appears slightly red immediately after use, this is normal and due to pressure and friction applied. during treatment.




When using the Body Hair Remover Head, the unit may not activate immediately when the ON button is pushed. If this occurs, gently tap the unit on a hard surface to activate. This is due to the different motor functions of the unit only, and is not indicative of its malfunction.

NOTE: It is normal for the unit heads to become warm with use. If unit begins to slow down, use the included brush to clean hair residue from unit heads. If unit is still running slow, change the battery.

CLEANING

Clean unit heads with included brush after each use.

- To clean, turn unit off.
- Twist head counter-clockwise to lift off. (Fig.8)
- Gently remove white stem from head and carefully brush away hair residue from stem and cutting surfaces. (Fig. 9)
- Gently brush away hair from inside head. (Fig.10)
- Replace stem inside head, then place head back on unit. Twist clockwise until locked in place.



Your Dermaline™ 3-in-1 Hair Remover is Waterproof! Feel free to use it in the shower or bath, but make sure the selected head is securely attached and the battery compartment securely closed.

CAUTION:

- Not intended for persons under 12 years of age.
- Use only as intended as per this manual.
- Do not use on irritated skin, open wounds or on breakouts. If skin irritation occurs, discontinue use.
- Exercise due caution when using unit around eye area. Do not contact eyelids or eyes with the unit.
- Do not put used batteries in fire as they could explode or leak. Dispose according to all local regulations.

WARNING:

- Keep out of reach of children

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. Supertek Canada Inc. shall not be liable for any incidental or consequential damages or any implied warranty on this product.

Distributed by:
Supertek Canada Inc.
Mont-Royal, QC H4T 1X2
www.clikit.ca
Customer Service: 1-800-304-8354