

IMPORTANT SAFETY INSTRUCTIONS, READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT. **INJURY CAN RESULT FROM IMPROPER USE.**

WARNING

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into this product.
- Avoid water and wet locations.
- · Do not use this product in the rain, near washbasins, or other wet locations.
- Be careful not to spill any food or liquid on this product.
- Do not expose this product to direct sunlight.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Use of a power supply or charger not recommended or sold by Atomic Charge Wallet
- manufacturer may result in a risk of fire or injury to persons.
- Do not use Atomic Charge Wallet in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- Do not disassemble Atomic Charge Wallet. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- Do not expose Atomic Charge Wallet to fire or excessive temperature. Exposure to fire or temperatures above 100°C (212°F) may cause an explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.

HOW TO CHARGE THE ATOMIC CHARGE WALLET



1. Using the USB cable supplied, plug the micro USB terminal into the input port of the Atomic Charge Wallet. (Figure A) Connect the other end of the cable into a USB port of a power source.



- 2. The blue LEDs will be on while it is being charged. The number of illuminated LEDs indicates the battery level. (Figure B)
- 3. Disconnect the USB cord when fully charged.

HOW TO CHARGE YOUR ELECTRONIC DEVICE

- 1. Plug the USB charging cord (supplied with your electronic device) into the USB output port of the fully charged Atomic Charge Wallet (Figure C), then connect the other end of the USB cord to your electronic device.
- 2. The electronic device will start charging, and it can be used while charging is in progress.
- 3. Check the charging status on your device.
- 4. Disconnect the USB cord when charging is completed. The Atomic Charge Wallet will turn off automatically.

TESTING THE BATTERY STATUS

1. To test the battery status of the Atomic Charge Wallet, simply press the button on the front side. The LED indicator will show the strength of the battery. (Figure D)



Battery Strength	LED Indicator	Remarks
Good	4 LEDs on	Fully charged. No recharging required.
Good to Average	3 LEDs on	-
Average	2 LEDs on	-
Weak	1 LED on	Recharge (optional).
Very Weak	Blinking LEDs	Recharge required.
No Power	No LED	Immediate recharge required.

PRODUCT SPECIFICATIONS

Input: DC 5V/1A	Battery Capacity: 3.7V 2500 mAh
Output: DC 5V/1A	Operating Temperature: 0°C – 40°C (32°F – 104°F)

STORING CASH AND CARDS

- 1. Fold bills in half and then insert into the wallet.
- 2. Credit cards will fit perfectly into the slots. (Figure E)



BATTERY DISPOSAL

When the battery can not be recharged anymore it should be recycled per the Federal, provincial and local regulations. This battery can not be incinerated or composted.

*∎*Supertek[™]

Distributed by Supertek Canada Inc. Mont-Royal, Qc H4T 1X2 Made in China

Customer Service: 1-800-304-8354

Version 3.0

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected

Consult the dealer or an experienced radio/TV technician for help.



Figure C