

Front



⚠ WARNING:

Prevent contact with eyes, skin and clothing. Liquid causes serious eye damage. Eye, skin, and respiratory irritant. Do not breathe vapor. Keep away from heat and flames. UV light can burn eyes and skin. Do not point UV light at people or animals. Keep children away from product. Modified acrylamide and mixed acrylates can cause eye, skin and respiratory irritation. Harmful if swallowed or in contact with skin or eyes. Wash product from skin or eyes immediately with water. Call physician if contact with eyes, or if skin irritation persists. If swallowed call physician or poison control center. Do not induce vomiting.

Fold

INSTRUCTIONS FOR USE

Please follow carefully

1. Make sure surfaces to be bonded are clean. Particles and grease may affect bonding.

2. Uncap LazerBond USA™ and apply a thin layer of adhesive using the applicator's precision tip (Figure 1). This layer should be thinner than 1 mm.




Figure 1

3. Place your entire finger pad over the button, squeeze to activate LED UV light, and point light at the layer of adhesive for 3-8 seconds to cure




Figure 2

LazerBond USA (Figure 2). If any tackiness remains, continue to cure adhesive with LED UV light until adhesive solidifies. To bond long areas, begin curing adhesive at one end, allowing each section to cure for 3-8 seconds before moving the LED UV light to the next section. Repeat until the full length of the adhesive has been cured.

Fold

4. Steps 2-3 can be repeated to layer LazerBond USA until you achieve your desired result.
5. Remove excess adhesive from the precision tip and recap LazerBond USA. Store at room temperature away from light and heat.
6. Allow bond to cool before handling.
7. Bond may be sanded smooth or painted to match surface.

Helpful Hints:

- For greater bond on smooth surfaces, roughen surfaces lightly with sandpaper and clean off residue before applying LazerBond USA.
- LazerBond USA will only harden when cured by UV light.
- Time required to cure LazerBond USA depends on a number of factors, including thickness of LazerBond USA layer, distance from UV LED to LazerBond USA, strength of UV LED, and opacity of the surface being bonded.
- Wearing gloves and eye protection during use is recommended. If LazerBond USA adhesive gets on skin, wash immediately with plenty of soap and water. If irritation persists, call a physician. If it gets in eyes, wash immediately with plenty of water and call physician.

Fold

Back

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. Supertek Canada Inc. shall not be liable for any incidental or consequential damages or any implied warranty on this product.

Designed for Telebrands in USA.
Adhesive Made in USA.
Applicator Made in China.



Distributed by:
Supertek Canada Inc.
Mont-Royal, Qc H4T 1X2
Customer Service: 1-800-304-8354